## **Basket Sizes**

ENDO-FLEX baskets sizes are measured in stretched condition, which means when the basket is retracted into the tube. Other manufacturers may measure basket sizes in opened condition and by indicating the height and width in mm.

### Conversion table for the different measuring methods:

ENDO-FLEX (stretched condition)	others (height x width)
40 mm	~ 28 x 15
50 mm	~ 37 x 20
60 mm	~ 45 x 25
70 mm	~ 50 x 30







### 4 wires / Basket-Type

#### basket-type

packing unit	basket size (in stretched condition)		
5 pieces	40 mm	50 mm	60 mm
braided wire	E 161 224	E 161 225	E 161 226



## 6 wires / Dormia-Type

#### dormia-type

packing unit	basket size (in str	basket size (in stretched condition)	
5 pieces	50 mm	60 mm	
braided wire	E 162 225	E 162 226	



# 4 wires / Basket-Type

• accepts guide wire .035 inch

#### basket-type

packing unit	basket size (in stretched condition)		
5 pieces	40 mm	50 mm	60 mm
braided wire	E 161 224GW	E 161 225GW	E 161 226GW









# 4 wires / Basket-Type

#### basket-type

	packing unit	basket size (in stretched condition)	
_	5 pieces	50 mm	60 mm
	monofilament wire	E 151 185	E 151 186



